

6677/03
5 LITRE

GLASSWASH RENOVATOR INFORMATION SHEET

USE:

A concentrated, low foaming glassware detergent formulated to quickly and efficiently remove 'bloom' & protein and yeast deposits from drinking glasses.

DIRECTIONS:

Withdraw the feeder tube from the normal glasswash detergent and place in the Glasswash Renovator.
(NOTE: If a high concentration glass or dishwash detergent is being used flush the system with clean water, before connecting to the Glasswash Renovator.)
Operate through the electronic dispenser unit at a ratio of 1-3ml per litre.
Proceed to clean the glassware in the normal manner.
Replace the feeder tube into the glasswash cleaning detergent when all glassware has been renovated.
It is advisable to renovate glassware on a monthly basis.
NOT TO BE USED FOR HAND GLASSWASHING.

TECHNICAL:

Physical state:	Liquid
Colour:	Light Yellow
Odour:	Hypochlorite
pH:	> 11.5
Density:	1.14 – 1.15

